




rosca m.10 / 70 X 70 / Ø 50



AR011200  balaustre 800 / 870  
**ARRANQUE GOYA ■ 1200 (int. 720)**  
 AR01CS12  soldar Fe  
**AR. GOYA METALICO ■ 1200 (int. 720)**

AR02  balaustre 870  
**ARRANQUE FLOR ■ 1200 (int. 840)**


AR030970  balaustre 700  
**ARRANQUE PERA ■ 970 (int. 642)**  
 AR031180  balaustre 800 / 870  
**ARRANQUE PERA ■ 1180 (int. 745)**



## Columnas de Arranque

## Start Pilars

rosca m.10 / 70 X 70 / Ø 50




- AR040820    balaustre 500 / 600  
AR. FLOR CUAD. ■ 820 (int. 460)
- AR041030    balaustre 700  
AR. FLOR CUAD. ■ 1030 (int. 670)
- AR041100    balaustre 800  
AR. FLOR CUAD. ■ 1100 (int. 750)
- AR041250    balaustre 870  
AR. FLOR CUAD. ■ 1250 (int. 820)





## BALAUSTRAS - COLUMNAS DE ARRANQUE / BALUSTERS - START PILARS



BA240500 ancho 260  
BALAUSTRE ALHAMBRA ■ 500

BA240700 ancho 260  
BALAUSTRE ALHAMBRA ■ 700

BA240870 ancho 260  
BALAUSTRE ALHAMBRA ■ 870



AR061250 balaustre 870  
AR. FLOR DADO BASE 70 X 70 ■ 1250 (int.800)

AR061350 balaustre 870  
AR. FLOR DADO BASE 100 X 100 ■ 1350 (int.800)



AR050940 balaustre 700  
AR. TROYA CON BASE ■ 940 (int.600)

AR051075 balaustre 800  
AR. TROYA CON BASE ■ 1075 (int.700)

AR051170 balaustre 870  
AR. TROYA CON BASE ■ 1170 (int.800)



AR081030 balaustre 700  
AR. PERA BASE 100 X 100 ■ 1030 (int.650)

AR081250 balaustre 870  
AR. PERA BASE 100 X 100 ■ 1250 (int.800)



AR071030 balaustre 700  
AR. FLOR BASE 100 X 100 ■ 1030 (int.650)

AR071250 balaustre 870  
AR. FLOR BASE 100 X 100 ■ 1250 (int.800)

